


# RCD18022A100 18V Akkuschauber m.100-tlg

5133001951 - RCD18022A100 - 4000444051





Position	Quantity	Description	Part number	EAN
1	1	ADAPTER SCHWEIZ	4931392302	4002395733965
2	1	LADEGERAET	Item discontinued(5131031689)	
3	2	BATTERIE	Item discontinued(5131031688)	
001 4	1	MOTOREINHEIT	5131029437	4058546119157
002 5	1	GETRIEBEKASTEN	Item discontinued(5131029438)	
003 6	1	SCHALTER M.ELEKTRONIK	Item discontinued(5131029439)	
004 7	1	KONTROLLEUCHE	Item discontinued(5131029440)	
005 8	1	MOTORGEHAEUSE	5131029441	4058546119188
006 9	1	BOHRFUTTER	5131029442	4058546119195
007 10	1	Schraube	5131001845	4058546083502
008 11	1	WECHSELKNOPF	5131029443	4058546119201
009 12	1	EINSTELLKNOPF	Item discontinued(5131029444)	
010 13	1	WASSERWAAGE	Item discontinued(5131017274)	
011 14	1	ETIKETT	5131019705	4058546067700
012 15	2	FEDERRING	Item discontinued(5131019721)	
013 16	1	SCHRAUBE	Item discontinued(5131011425)	
014 17	7	SCHRAUBE	5131011359	4058546168315
015 18	2	SCHRAUBE	Item discontinued(5131029445)	
016 19	1	MAGNET	5131029446	4058546119232
017 20	1	Bithalter	Item discontinued(5131002001)	
019 21	1	ETIKETT	Item discontinued(5131029448)	
020 22	1	BUNDBUCHSE	Item discontinued(5131029449)	
018 23	1	DOUBLE BIT (PH2 S6 L=50MM)	Item discontinued(5132001236)	