


RLT1831CD3H 18V TRIMMER+AKKUSCHR EU

5133002255 - RLT1831CD3H - 4000444183



RLT183113



090932006

Position	Quantity	Description	Part number	EAN
1	1	ADAPTER SCHWEIZ	4931392302	4002395733965
0001 2	1	BATTERIE	Item discontinued(5131031688)	
0002 3	1	LADEGERAET	Item discontinued(5131031689)	
1_001 4	17	SCHRAUBE	5131034734	4058546143275
1_004 5	1	SCHUTZ	Item discontinued(5131035446)	
1_005 6	1	DECKEL	5131034743	4058546143367
1_015 7	1	GEHAEUSE	5131034666	4058546142803
1_016 8	2	Schraube	5131035447	4058546148690
1_017 9	1	PLATTE	5131035448	4058546148706
1_018 10	1	MOTOR	5131035109	4058546146146
1_019 11	1	MOTOR	5131035449	4058546148713
1_021 12	1	SCHUTZ	5131035450	4058546148720
1_022 13	1	GEHAEUSE	5131035451	4058546148737
1_023 14	1	FEDER	5131035115	4058546146191
1_024 15	1	KNOPF	Item discontinued(5131035116)	
1_025 16	1	BLECH	5131035117	4058546146214
1_026 17	1	ANSCHLUSS	Item discontinued(5131034675)	
1_027 18	1	GEHAEUSE	5131035452	4058546148744
1_028 19	1	HANDGRIFF	Item discontinued(5131035124)	
1_034 20	1	LEITUNG	5131035114	4058546146184
1_035 21	1	WELLE	Item discontinued(5131035453)	
1_047 22	1	FEDER	5131035454	4058546148768
1_048 23	1	DRUECKER	5131035455	4058546148775
1_049 24	1	VERSCHLUSS	5131035456	4058546148782
1_050 25	1	FEDER	5131035457	4058546148799
1_051 26	1	UMSCHALTER	Item discontinued(5131034682)	
1_052 27	1	ANSCHLUSSPLATTE	5131035461	4058546011659
1_053 28	1	LEITUNG	5131034676	4058546142872
1_054 29	9	SCHRAUBE	Item discontinued(5131011407)	
1_055 30	1	HANDGRIFF	5131035458	4058546148805