


# RLT36C3325/1x2.5Ah Akku-Rasentrimmer IN2

5133002107 - RLT36C3325 - 4000444186



**RYOBI**

**RLT36C33**



090925004

Position	Quantity	Description	Part number	EAN
0002 1	1	LADEAGGREGAT	Item discontinued(5131026908)	
1_001 2	5	SCHRAUBE	5131034734	4058546143275
1_008 3	1	SCHUTZ	Item discontinued(5131034741)	
1_009 4	1	SCHUTZ	Item discontinued(5131034742)	
1_010 5	1	DECKEL	5131034743	4058546143367
1_013 6	1	FEDER	5131034745	4058546143381
1_014 7	1	FUEHRUNGSPLATTE	5131034746	4058546143398
1_015 8	1	BLECH	5131034747	4058546143404
1_016 9	2	BLECH	5131034748	4058546143411
1_017 10	1	GEHAEUSE	5131041862	4058546250768
1_018 11	16	SCHRAUBE	5131035877	4058546152673
1_019 12	1	GEHAEUSE	Item discontinued(5131034751)	
1_020 13	2	MOOSGUMMI	Item discontinued(5131034752)	
1_021 14	2	ANSCHLUSSKLEMME	5131035584	4058546149932
1_022 15	1	MOTOR	Item discontinued(5131034754)	
1_023 16	1	KONSOLE	5131034755	4058546143459
1_024 17	2	SCHRAUBE	5131034756	4058546143466
1_025 18	1	AUSGLEICHGEWICHT	Item discontinued(5131034757)	
1_037 19	1	ROHR	Item discontinued(5131034769)	
1_038 20	1	MOTOREINHEIT	5131034770	4058546143497
1_047 21	1	ROHR	Item discontinued(5131034779)	
1_048 22	1	SCHRAUBE	5131034780	4058546143510
1_050 23	1	HALTER	Item discontinued(5131034782)	
1_051 24	1	VERBINDUNG	Item discontinued(5131034783)	
1_052 25	2	ANSCHLUSS	5131035625	4058546150327
1_053 26	1	ANSCHLUSSPLATTE	5131034785	4058546143558
1_054 27	2	SCHRAUBE	5131035627	4058546150341
1_055 28	1	VERSCHLUSS	5131035100	4058546146061
1_056 29	1	FEDER	5131034788	4058546143572
1_057 30	1	DRUECKER	5131034789	4058546143589
1_058 31	1	UMSCHALTER	5131034790	4058546143596
1_069 32	1	HANDGRIFF	Item discontinued(5131034793)	
1_070 33	1	HANDGRIFF-SET	5131034794	4058546143633
1_036 34	1	RAC142 Fadenspule 2.0 mm	5132002769	4892210133281