


# RLT5027 Elektro-Trimmer IN2

5133002117 - RLT5027 EU - 4000444196



# RYOBI

## RLT5027



Position	Quantity	Description	Part number	EAN
1	1	ADAPTER SCHWEIZ	4931392302	4002395733965
1_001 2	26	SCHRAUBE	5131034865	4058546144104
1_002 3	1	SCHRAUBE	Item discontinued(5131034866)	
1_003 4	1	HANDGRIFF	Item discontinued(5131034867)	
1_004 5	1	ANSCHLUSS	5131034868	4058546144135
1_005 6	1	SCHALTER	5131035423	4058546148584
1_006 7	1	DRUECKER	5131034870	4058546144159
1_007 8	1	FEDER	5131034871	4058546196783
1_008 9	1	WELLE	Item discontinued(5131035420)	
1_009 10	3	KLEMME	Item discontinued(5131034873)	
1_010 11	1	KABELSCHUTZSCHLAUCH	Item discontinued(5131034874)	
1_011 12	1	KABEL	5131034876	4058546144180
1_012 13	1	KNOPF	Item discontinued(5131034877)	
1_013 14	1	HANDGRIFF	5131034878	4058546144203
1_014 15	1	MUTTER	5131034879	4058546144210
1_015 16	1	KONSOLE	5131034880	4058546144227
1_016 17	1	GEHAEUSE	5131034881	4058546144234
1_017 18	1	GEHAEUSE	5131034882	4058546144241
1_018 19	1	FEDER	Item discontinued(5131034883)	
1_019 20	1	KNOPF	5131034884	4058546144265
1_020 21	1	MOOSGUMMI	5131034885	4058546144272
1_021 22	1	MOTOR	5131035421	4058546148560
1_022 23	1	RAC122 1.5mm Fadenspule RLT4027	5132002670	4892210819680
1_023 24	1	DECKEL	5131034887	4058546144296
1_024 25	1	SCHUTZ	5131034888	4058546144302
1_025 26	1	SCHUTZ	5131034889	4058546144319
1_026 27	1	KONDENSATOR	Item discontinued(5131034890)	
1_027 28	1	FUEHRUNGSHUELSE	Item discontinued(5131034891)	
1_028 29	1	DECKEL	5131034892	4058546144340
1_029 30	1	FEDER	Item discontinued(5131041171)	
1_030 31	1	SCHIEBER	5131041172	4058546064365
32	1	RAC122 1.5mm Fadenspule RLT4027	5132002670	4892210819680