


RSH2845T 2800W Elektro-Leisehaecksler IN

5133002351 - RSH2845T - 4000444367



RYOBI

4000444367
4000444368



Position	Quantity	Description	Part number	EAN
001 1	4	SCHRAUBE	Item discontinued(5131036323)	
002 2	1	SCHALTER	5131036324	4058546156947
003 3	1	SCHALTER	Item discontinued(5131036325)	
004 4	1	STEUERSCHALTER KOMP	Item discontinued(5131036326)	
005 5	1	BEDIENUNGSKONSOLE	Item discontinued(5131036327)	
006 6	1	DECKEL	5131036328	4058546156985
007 7	2	PLATTE	Item discontinued(5131036329)	
008 8	8	SCHRAUBE	5131036330	4058546157005
009 9	1	Trichter fuer Haecksler	5131036331	4058546157012
010 10	1	ROHR	Item discontinued(5131036332)	
011 11	1	PLATTE	Item discontinued(5131036333)	
012 12	1	DECKEL	Item discontinued(5131036334)	
013 13	1	GEHAEUSE	Item discontinued(5131036335)	
014 14	1	ELEKTRISCHES KABEL	5131036336	4058546157067
015 15	1	KABELSCHUTZSCHLAUCH	Item discontinued(5131036338)	
016 16	3	KABELKLEMME	Item discontinued(5131036339)	
017 17	24	SCHRAUBE	Item discontinued(5131036340)	
018 18	15	SCHRAUBE	5131036341	4058546157111
019 19	1	ELEKTRONIK-PLATINE	5131036342	4058546157128
020 20	1	SCHALTER	Item discontinued(5131036343)	
021 21	1	KABELSCHUTZSCHLAUCH	Item discontinued(5131036344)	
022 22	1	LEITUNG	Item discontinued(5131036345)	
023 23	1	LEITUNG	Item discontinued(5131036346)	
024 24	1	GEHAEUSE UNTEN	Item discontinued(5131036347)	
025 25	2	SCHRAUBE	Item discontinued(5131036348)	
026 26	1	DECKEL	Item discontinued(5131036349)	
027 27	1	GESTELL	Item discontinued(5131036350)	
028 28	1	LEITUNG	Item discontinued(5131036351)	
029 29	1	LEITUNG	Item discontinued(5131036352)	
030 30	1	LEITUNG	Item discontinued(5131036353)	
031 31	1	LEITUNG	Item discontinued(5131036354)	
032 32	1	LEITUNG	Item discontinued(5131036355)	
033 33	1	LEITUNG	Item discontinued(5131036356)	
034 34	1	LEITUNG	Item discontinued(5131036357)	
035 35	1	MOTOREINHEIT	Item discontinued(5131036358)	
036 36	1	SCHEIBE	Item discontinued(5131036360)	
037 37	2	SCHRAUBE	Item discontinued(5131036361)	
038 38	1	GETRIEBE-SET	Item discontinued(5131036362)	
039 39	1	SCHEIBE	5131036363	4058546157319
040 40	3	GETRIEBE-SET	Item discontinued(5131036364)	
041 41	1	WELLE	Item discontinued(5131036365)	
042 42	1	LEITUNG	Item discontinued(5131036366)	
043 43	1	VERRIEGEL.-ELEMENT	5131036367	4058546157357
044 44	1	KLINGENGEHAEUSE	Item discontinued(5131036368)	
045 45	4	BOLZEN	Item discontinued(5131036369)	
046 46	1	PLATTE	5131036370	4058546157388
047 47	6	SCHRAUBE	5131036371	4058546157395
048 48	1	PASSFEDER	5131036372	4058546157401
049 49	1	MUTTER	5131036373	4058546157418
050 50	1	PLATTE	5131036374	4058546157425

Position	Quantity	Description	Part number	EAN
051 51	1	SCHERBLATT	Item discontinued(5131036375)	
052 52	1	STELLBLECH	Item discontinued(5131036376)	
053 53	1	SCHUTZHAUBENDECKEL	Item discontinued(5131036377)	
054 54	1	SCHUTZHAUBENDECKEL	Item discontinued(5131036378)	
055 55	4	BOLZEN	5131036379	4058546157470
057 56	1	DECKEL	5131040944	4058546062088
059 57	1	STUETZBLECH	Item discontinued(5131036383)	
060 58	1	DECKEL	Item discontinued(5131036384)	
061 59	1	KONDENSATOR	Item discontinued(5131036385)	
062 60	1	DECKEL	Item discontinued(5131036386)	
063 61	2	SCHRAUBE	Item discontinued(5131036387)	
064 62	2	SCHRAUBE	5131036388	4058546157562
065 63	1	SCHALTHEBEL	5131036389	4058546157579
066 64	1	HANDGRIFFHALTER	Item discontinued(5131036390)	
067 65	1	GRIFF	5131036391	4058546157593
068 66	1	SCHNITTGUTBEHAELTER	Item discontinued(5131036392)	
069 67	1	SCHRAUBE	5131036393	4058546157616
070 68	2	DECKEL	5131036394	4058546157623
071 69	2	BOLZEN	Item discontinued(5131036395)	
072 70	2	WELLE	5131036396	4058546157647
073 71	2	SCHEIBE	5131036397	4058546157654
074 72	2	MUTTER	Item discontinued(5131036398)	
075 73	2	BOLZEN	Item discontinued(5131036399)	
076 74	2	Untergestell fuer Haecksler	5131036400	4058546157685
077 75	2	MUTTER	Item discontinued(5131036401)	
078 76	2	ABDECKKRAHMEN	Item discontinued(5131036402)	
079 77	2	ABDECKKRAHMEN	Item discontinued(5131036403)	
080 78	2	SCHNELLBEFESTIGER	Item discontinued(5131036404)	
081 79	8	KABELSCHUTZSCHLAUCH	Item discontinued(5131036405)	
082 80	1	SCHLUESSEL	Item discontinued(5131036406)	
083 81	1	FEDER	5131040945	4058546062095
084 82	1	SCHEIBE	5131040946	4058546062101
085 83	1	SCHRAUBE	Item discontinued(5131040947)	
086 84	1	SCHLUESSEL	Item discontinued(5131040948)	
087 85	1	SICHERUNGSRING	Item discontinued(5131036359)	