







# R18CS-0 18V Akku-Handkreissaege XXX

5133002338 - R18CS-0 18V - 4000444425





4000444425



Position	Quantity	Description	Part number	EAN
022 1	1	FLANSCH	5131041789	4058546250034
024 2	1	SPANNFLANSCH	5131049170	4058546605735
025 3	1	SCHRAUBE	5131030406	4058546124618
034 4	1	GRUNDKOEPPER	5131041243	4058546065072
042 5	1	ANSCHLAG	5131001023	4058546338626
043 6	1	VERBINDUNGSSTUECK	5131041216	4058546064808
050 7	1	SCHALTER M.ELEKTRO.	Item discontinued(5131033403)	
051 8	1	MOTOREINHEIT	Item discontinued(5131033404)	
052 9	1	GETRIEBEGEHAEUSE	5131033405	4002395161997
053 10	1	RITZEL	Item discontinued(5131033406)	
11	1	CSB165A1 Saegeblatt 165mm 40Z 16mm Bohru	5132002774	4892210135599