


# R18JS7-0 18V BL Akku-Stichsaeger XXX

5133004223 - R18JS7-0 - 4000462848





4000462848



Position	Quantity	Description	Part number	EAN
1039 1	1	DREHZAHLREGLER	5131042197	4058546254117
1045 2	1	SCHUTZSCHUH	5131042198	4058546254124
1059 3	1	ETIKETT	5131019705	4058546067700
1060 4	1	ETIKETT	5131042188	4058546254025
1061 5	1	ETIKETT	5131042189	4058546254032
1062 6	1	ETIKETT	5131042190	4058546254049
1070 7	1	SAEBELSAEGEBLATTAUFNahme	5131042191	4058546254056
1071 8	1	AUSGLEICHGEWICHT	5131042192	4058546254063
1072 9	1	FUEHRUNGSROLLE	5131042193	4058546254070
1073 10	1	DRUECKER	5131042194	4058546254087
1074 11	1	GEHAEUSE	5131042195	4058546254094
1076 12	1	GRUNDPLATTE	5131042196	4058546254100