


# RY18CS20A-0 AKKU-KETTENSAEGE

5133005414 - RY18CS20A-0 - 4000475916





4000475916



Position	Quantity	Description	Part number	EAN
1001 1	1	SCHRAUBE	5131045495	4058546430870
1002 2	1	EINSTELLVORRICHTUNG	5131045496	4058546430887
1003 3	1	KETTENSAEGESCHWERT	5131049166	4058546605698
1008 4	1	SCHWERTSCHUTZ	5131045497	4058546430894
1009 5	1	SCHEIBE	5131037503	4002395288328
1010 6	1	ABDECKUNG	5131045498	4058546430900
1012 7	1	HANDSCHUTZ	5131045499	4058546430917
1013 8	1	SICHERUNGSRING	5131037498	4002395287673
1014 9	1	RITZEL	5131037502	4002395288311
1015 10	1	ANTRIEBSSCHAFT	5131045500	4058546430924
1016 11	1	MOTOREINHEIT	5131045501	4058546430931
1018 12	1	DRUECKER	5131045502	4058546430948
1019 13	1	DC-MOTOR	5131045503	4058546430955
1020 14	2	GUMMIPLATTE	5131035568	4058546149772
1023 15	1	HANDGRIFF	5131045504	4058546430962
1024 16	1	SCHLUESSEL	5131045505	4058546430979
1004 17	1	RAC270 SAeGEKETTE, 20 CM	5132005416	4892210204547