


RY18GSA-120B GRAS+STRAUCHSCHERE GB2

5133006238 - RY18GSA-120B - 4000486449

RYOBI

4000486449



Position	Quantity	Description	Part number	EAN
1001 1	1	MESSERSCHUTZ	5131046558	4058546461904
1004 2	1	MESSERSCHUTZ	5131046559	4058546461911
1005 3	1	ZAHNRAD	Item discontinued(5131009074)	
1006 4	2	SCHEIBE	5131034707	4058546143046
1007 5	2	SCHRAUBE	5131049509	4058546609122
1008 6	2	SCHEIBE	Item discontinued(5131017800)	
1009 7	1	HALTERUNG	5131049724	4058546611279
1010 8	1	MESSERSCHUTZ	5131046558	4058546461904
1012 9	2	PUFFER	5131049725	4058546611286
1013 10	1	DC-MOTOR	5131049726	4058546611293
1014 11	1	DRUECKER	5131049727	4058546611309
1015 12	1	FEDER	5131049728	4058546611316
1016 13	1	DRUECKER	5131049729	4058546611323
1017 14	1	DRUECKER	5131049730	4058546611330
1018 15	1	FEDER	5131049731	4058546611347
1019 16	1	SCHALTER	5131049732	4058546611354
1020 17	1	KLEMME	5131049733	4058546611361
1021 18	1	FEDER	5131043640	4058546350000
1022 19	1	ELEKTRONIK	5131049734	4058546611378
1023 20	1	DECKEL	5131049735	4058546611385
1024 21	1	SCHIEBER	5131049736	4058546611392
1025 22	1	FEDER	5131034745	4058546143381
1026 23	1	SCHALTER	5131049737	4058546611408
1027 24	2	KONTAKTEINSATZ	5131049738	4058546611415
1028 25	6	SCHRAUBE	5131045185	4058546650223
1029 26	2	SCHRAUBE	5131045186	4058546650230
1030 27	1	GEHAEUSE	5131049739	4058546611422
1033 28	1	LEITUNG	5131042623	4058546258375
1035 29	1	LEITUNG	5131049740	4058546611439
1036 30	1	LEITUNG	5131049741	4058546611446
1037 31	1	LEITUNG	5131049742	4058546611453
1002 32	1	RAC323 Shrubber Blade for RY18GSA XXX	5132005965	4892210223258
1011 33	1	RAC322 Shear Blade for RY18GSA XXX	5132005964	4892210223241