


# **RY18PSX10A-120 AKKU-KETTENSAEGE IN2**

**5133005434 - RY18PSX10A-120 - 4000486457**

# RYOBI

4000486457



Position	Quantity	Description	Part number	EAN
1001 1	2	SCHRAUBE	5131034780	4058546143510
1003 2	1	GRIFFDECKEL	5131046796	4058546464288
1004 3	1	SPANNEINRICHTUNG	5131046797	4058546464295
1005 4	1	KETTENSAEGESCHWERT	5131046596	4058546462284
1006 5	1	SCHWERTSCHUTZ	5131046798	4058546464301
1007 6	2	SCHRAUBE	5131046799	4058546464318
1009 7	1	SCHRAUBE	5131037515	4002395284528
1010 8	1	SCHEIBE	5131046034	4058546456665
1011 9	1	HANDSCHUTZ	5131046800	4058546464325
1012 10	1	FEDER	5131046801	4058546464332
1013 11	1	RING	5131044598	4054278820194
1014 12	1	SCHEIBE	5131046802	4058546464349
1015 13	1	ZAHNRAD	5131046803	4058546464356
1016 14	1	SCHRAUBE	5131045040	
1017 15	1	GEHAEUSE	5131046804	4058546464363
1018 16	1	SCHALTER	5131046805	4058546464370
1019 17	1	PLANETENGETRIEBE	5131046806	4058546464387
1020 18	1	GETRIEBE	5131046807	4058546464394
1021 19	1	ANTRIEBSWELLE	5131046808	4058546464400
1022 20	1	DC-MOTOR	5131046809	4058546464417
1023 21	1	FEDER	5131046810	4058546464424
1024 22	1	DRUECKER	5131046811	4058546464431
1025 23	1	DRUECKER	5131046812	4058546464448
1026 24	1	FEDER	5131045096	4058546400170
1008 25	1	RAC274 Saegekette 10 cm	5132005435	4892210204554