




RSCR4-0 4V USB SCHRUBBER XXX

5133006184 - RSCR4-0 - 4000486569







4000486569



10



2

Position	Quantity	Description	Part number	EAN
1001 1	1	BUERSTE	5131047568	4058546502041
1002 2	1	USB KABEL	5131047409	4058546500467
1010 3	1	DECKEL	5131047592	4058546502287