


# RHC4-0 4V USB HEISSDRAHTSCHNEIDER XXX

5133006182 - RHC4-0 - 4000486589



# RYOBI

4000486589



<b>Position</b>	<b>Quantity</b>	<b>Description</b>	<b>Part number</b>	<b>EAN</b>
1004 1	1	HEIZDRAHTHALTERUNG	5131047604	4058546502409
1005 2	1	GRAVIERSPITZE	5131047605	4058546502416
1006 3	1	MESSERSPITZE	5131047606	4058546502423
1007 4	1	KLEMMSTUECK	5131047716	4058546503529
1008 5	1	DRAHT	5131047613	4058546502492
1009 6	1	BATTERIEDECKEL	5131047609	4058546502454
1010 7	1	USB KABEL	5131047409	4058546500467