


RY18BLXD-0 AKKU-LAUBBLAESER XXX

5133005948 - RY18BLXD-0 - 4000486615



RYOBI

4000486615



Position	Quantity	Description	Part number	EAN
1001 1	1	ELEKTRONIK	5131047537	4058546501730
1002 2	1	GEHAEUSE	5131047538	4058546501747
1003 3	1	DECKEL	5131047539	4058546501754
1004 4	1	FUEHRUNGSROHR	5131047540	4058546501761
1005 5	1	ALLZWECKDUESE	5131047541	4058546501778
1006 6	1	FERRITKERN	5131044437	4058546398569
1007 7	1	DC-MOTOR	5131047542	4058546501785
1008 8	1	ROHR	5131047543	4058546501792
1009 9	1	DUESE	5131047544	4058546501808
1010 10	1	DRUECKER	5131046004	4058546456368
1011 11	1	DRUECKER	5131046022	4058546456542
1012 12	1	DREHKNOPF	5131046005	4058546456375
1013 13	1	DRUECKER	5131046024	4058546456566
1014 14	1	SCHALTER	5131046775	4058546464073
1015 15	4	GUMMIPUFFER	5131043684	4058546350444
1016 16	15	SCHRAUBE	5131035877	4058546152673
1017 17	1	SCHEIBE	5131042928	4058546261429
1018 18	1	SCHEIBE	5131046006	4058546456382
1019 19	1	FEDER	5131044530	
1020 20	1	FEDER	5131046007	4058546456399
1021 21	2	SCHRAUBE	5131047546	4058546501822
1022 22	1	BUEGEL	5131047547	4058546501839
1023 23	1	ETIKETT	5131047548	4058546501846
1024 24	1	ETIKETT	5131047549	4058546501853
1025 25	1	GITTER	5131047550	4058546501860