


# RFN1834X-0 AKKU-NAGLER XXX

5133006361 - RFN1834X - 4000486916



# RYOBI

## 4000486916



Position	Quantity	Description	Part number	EAN
1001 1	1	MAGAZIN	5131048346	4058546544751
1002 2	1	SCHLUESSEL	5131048347	4058546544768
1003 3	1	STOESSEL	5131048348	4058546544775
1004 4	1	NASENSTUECK	5131048349	4058546544782
1005 5	1	ELEKTRONIK	5131048350	4058546544799
1006 6	1	DECKEL	5131048351	4058546544805
1007 7	1	SCHRAUBE	5131048352	4058546544812
1008 8	1	ZYLINDER	5131048353	4058546544829
1009 9	1	SCHRAUBE	5131048354	4058546544836
1010 10	1	KLEMME	5131048355	4058546544843
1011 11	1	DECKEL	5131048356	4058546544850
1012 12	1	HAKEN	5131048357	4058546544867
1013 13	1	GEHAEUSE	5131048358	4058546544874
1014 14	1	DRUECKER	5131048359	4058546544881
1015 15	1	DRUECKER	5131048360	4058546544898
1016 16	1	DRUECKER	5131048361	4058546544904
1017 17	15	SCHRAUBE	5131038140	4058546006549
1018 18	2	HALTERUNG	5131048362	4058546544911
1019 19	1	LEISTUNGSSCHILD	5131048363	4058546544928