


# R1801WSLN-0 AKKU-KREISSAEGE XXX

5133006798 - R1801WSLN - 4000504510



# RYOBI

## 4000504510



Position	Quantity	Description	Part number	EAN
1001 1	1	SCHRAUBE	5131030406	4058546124618
1002 2	1	Flansch aussen Saegeblatt	5131001795	4058546083298
1003 3	1	SPANNFLANSCH	5131030407	4058546124625
1004 4	4	SCHRAUBE	5131044776	4058546384999
1006 5	1	TRENNSCHUTZHAUBE	5131030408	4058546124632
1010 6	1	TRENNABSAUG-SET	5131030410	4058546185985
1011 7	1	GEHAEUSE	5131049167	4058546605704
1015 8	1	MOTORGEHAEUSE	5131030415	4058546124656
1016 9	2	MUTTER	5131030416	4058546186029
1017 10	1	SCHRAUBE	5131030417	4058546124663
1019 11	1	VERBINDUNGSSTUECK	5131030419	4058546124670
1021 12	1	SCHALTER	5131030421	4058546124687
1022 13	1	ARRETIERSTIFT	5131030422	4058546186050
1023 14	1	DRUECKER	5131048495	4058546546243
1024 15	1	MOTOR	5131006707	4058546090463
1026 16	1	GETRIEBEBEDECKEL	5131030423	4058546124694
1029 17	1	KONTERSTIFT	5131030424	4058546124700
1031 18	1	HALTER	5131030425	4058546124717
1032 19	1	CSB150A1 Saegeblatt 150/10mm 18Z	5132002579	4892210120465
1033 20	1	T-SCHLUESSEL	5131029524	4058546002091
1035 21	1	SAEGETISCH	5131049168	4058546605711
1036 22	1	DREHKNOPF	5131030427	4058546124731
1038 23	1	SCHRAUBE	5131030428	4058546124748
1039 24	1	ANSCHLAG	5131001023	4058546338626
1040 25	1	SCHAFT	5131016453	4058546103965
1041 26	1	LASERDIODE	5131043413	4058546266271
1042 27	1	LEISTUNGSSCHILD	5131049169	4058546605728